


# SETUP

Press back on battery cover tab then pull down to open



Insert a 9v Lithium based battery. If the bell is not ringing then the battery is likely underpowered and may cause it to behave inconsistently. Contact SCIRE for good rechargeable batteries.

## PRO TIP

Try using the Envirobell alongside other devices.

It uses the same sensors and pattern recognition as other SCIRE devices which means if they are triggered, the Envirobell can be too!

**SCIRETECH.CO.UK**

Discover everything you need on the SCIRE website to access cutting-edge, science based devices



**EXCLUSIVE CODE**

At checkout enter the single use discount code SCIRETECH

**SCIRE**  
**SCIRETECH.CO.UK**



**ENVIROBELL**  
V4.2

contact@sciretech.co.uk

# ALERTS

**LOW  
BATTERY**

**CALIBRATION**

**MONITORING**

Whilst flashing yellow put it down before it turns solid yellow to calibrate. The Envirobell will turn green which means it is monitoring the Enviroment. Change the battery if it turns red **WITHOUT** ringing.

**CATBALL  
EXPERIMENT**

**EMF**

Electromagnetic energy can trigger both the EMF alert and Catball Exeriment. The EMF sensor is calibrated to not be triggered by domestic electric, wifi or mobile phones.



**MINOR AIR**

**MAJOR AIR**

A pattern of Air pressure fluctuation linked to paranormal events has been detected. The Major level is highly anomalous.



**HOT**

**COLD**

A sudden sharp drop or increase in local temperature indicates a Hot or Cold spot



**NORTH**

**SOUTH**

Either a North or South Polarity change in the magnetic field compared to the calibrated levels.